

# HEPA FILTERED CART AIR SHOWERS PASS THRUS

## STANDARD FEATURES:

- 304 stainless steel construction with #4 finish.
- High volume HEPA filtration 99.99% efficient @ .3 microns.
- Recirculating Configuration.
- Integral ceiling mounted LED lighting.
- Low wall air returns with 30% efficient pre-filtration.
- Multi-directional air jet nozzles providing 5,000 FPM @ nozzle outlets.
- Automatic sensor-activated shower cycle.
- Adjustable cycle timer.
- 36" CLO doors with full lite safety glass (heavy duty construction).
- Pull type door latch hardware 304 SS.
- Pneumatic door closers.
- Clear acrylic full light door glass.
- Lighted rocker type power and light switches.
- System occupied indicator lights at entry and egress.
- Single point electrical connection.
- Minihelic Differential Pressure Gauge to monitor filter SP.

## OPTIONAL FEATURES:

- 316L stainless steel construction with #4 finish.
- ULPA filtration 99.9995% efficient @ .12 microns.
- Optional voltages in 230 v 60 hz 1 ph, and 277 v 60 hz 1 ph
- Electro magnetic interlocked doors.
- Cross flow configuration.
- Laminar downflow configuration.
- Integral flow-through lighting.
- Solid doors/sliding doors.
- Automatic swing-out or roll-up doors.
- Robot door control interface.
- CI-1 Div-1, CI-1 Div-2, CI-2 Div 1
- Custom sizes and configurations.

## NOTE:

- All filters are PSL challenged at factory to insure media integrity. Certificates of conformance are available upon request.
- Unit performance meets or exceeds standards as specified in Fed. Std. 209E / ISO 5 and IES-RP-CC-002.
- All electrical wiring is in conformance with NEMA standards.



MODEL	O.A. UNIT SIZE	INTERIOR SIZE	STD ELECTRICAL
CAS-336	44"w X 40"d X 90"h	36"w X 36"d x 72"h	115V 60 HZ 1 PH
CAS-346	44"w X 52"d X 90"h	36"w X 48"d x 72"h	115V 60 HZ 1 PH
CAS-356	44"w X 64"d X 90"h	36"w X 60"d x 72"h	115V 60 HZ 1 PH

\*All information herein is subject to change without notice.

\*All catalog dimensions are nominal.



© 7/2021